


Ride On Ladybird & Bumble Bee

Assembly Instructions


mocka

Thank you for your purchase.
Please follow the instructions below for correct assembly.



IMPORTANT - PLEASE RETAIN FOR FUTURE REFERENCE

The Mocka Ride On Ladybird is designed for one rider at a time and is suitable for children aged 18 months and older with a maximum of 25kg.



Ride On Ladybird & Bumble Bee

Assembly Instructions

mocka


CARE AND MAINTENANCE

Before riding the Mocka Ride on Ladybird or Bumble Bee for the first time, and before each future ride, please ensure that all parts are secure and that there is no damage from previous use. Please ensure all fastenings and wheels are tight and that the wheels rotate freely. If any part is broken or damaged, discontinue use immediately. Failure to do so may result in injury.

To clean, wipe the Mocka Ride on Ladybird/Bumble Bee with a damp, clean cloth.

WARNING

The Mocka Ride on Ladybird/Bumble Bee is to be used under adult supervision at all times. To prevent risk of falling, the Mocka Ride on Ladybird/Bumble Bee must be on clean, level surfaces. It must not be used near roads, water (including ponds, rivers and swimming pools), stairs or hills. Riders must wear shoes at all times.



Attach the handle bar [1] to the main body [2] as shown, using 2x washers (C), 2x rings (B) and 2x screws (A). Secure and tighten using the allen key (D). You're done, enjoy!