

Thank you for purchasing a Mocka rocking horse.

Please see instructions below for correct assembly.

mocka

WARNING- Small parts are used to assemble the Rocking Horse. Only an adult should assemble the Rocking Horse. Keep all assembly parts away from small children.

Supervise your child at all times.

Ensure your child is always well supervised when rocking to ensure the horse does not tip.

Regularly check all screws are secure.

Maximum weight limit is - 45kg

Recommended age up to 2 ½ years



ASSEMBLY INSTRUCTIONS

