



Hello,
I've arrived!

Now that I'm here you are only one
flat-pack away from transforming
your home.



Mocka.

Thank you for supporting us.

We believe design belongs to everyone. From materials and processes to safety testing, production and delivery, we are passionate and committed to bringing you the best possible product so you can create beautifully functional spaces to feel comfortably you.

Here are a few assembly tips before you get started:



Make Time

The first step to all seamless assembly is taking a moment to carefully read through the instructions—you are already on your way to creating a beautifully functional space!



Set The Mood

Put on your favourite playlist, order that pizza and pour yourself a drink to get in the mood!



Tool Check

Layout the instructions, screws and panels to check you have everything you need. A blanket or soft floor rug will help protect your new favourite item from scratches and a drill will speed up the assembly too!



Room Reveal

You did it! Take a step back and enjoy the moment. Don't forget to recycle any packaging and share a pic of your room reveal - we love seeing how you transform your home! Tag us @mockaaustralia/@mockaanz

Happy flat-packing!

The Mocka Team

Balley Mesh Bouncer

Thank you for purchasing Balley Mesh Bouncer. Please follow the manufacturer's assembly instructions in detail.

IMPORTANT! READ ALL INSTRUCTIONS BEFORE USE OF THE INFANT BOUNCER SEAT AND KEEP FOR FUTURE REFERENCE.

THIS BOUNCER IS NOT A SAFE SLEEPING SURFACE
NEVER LEAVE BABY UNATTENDED

⚠ WARNING ⚠

Fall Hazard: Babies have suffered skull fractures falling while in and from bouncers.

- Use bouncer only on floor.
- Always use restrains and adjust to fit snugly.
- Never lift or carry baby in bouncer.




Suffocation Hazard: Babies have suffocated when bouncers have tipped over on soft surfaces and/or when bouncers have been used as a sleep product.

- Never use on a bed, sofa, cushion, or other soft surface.
- Stay near and watch baby during use. This product is not safe for sleep or unsupervised use. If baby falls asleep, remove baby as soon as possible and place baby on a firm, flat sleep surface such as a crib or bassinet.

To prevent falls and suffocation:

- Always use restraints and adjust to fit snugly.
- Stop using bouncer when baby starts trying to sit up or has reached 9kg, whichever comes first.
- FOLLOW THE MANUFACTURES INSTRUCTIONS CAREFULLY AND ONLY USE BOUNCER FOR ITS INTENDED USE.




CLEANING & CARE


- Do not use the product unless all components are correctly fitted and adjusted. Regularly inspect the bouncer for maintenance of loose screws etc. Do not use the bouncer if any part is broken, torn, or missing. Contact MOCKA for further advice.
- Keep the Bouncer away from fire or any heat source.
- Cover: Remove all liquid food spills immediately. Cold Hand Wash. Do not Tumble Dry. Do not Dry Clean. Do not Bleach. Keep out of direct sunlight to avoid colour fading.
- Frame: Keep away from fire. Wipe the Bouncer frame clean using a clean damp cloth and suitable commercial cleaner. Wipe dry.

Mocka.




Balley Mesh Bouncer



1





+




Carefully pass the seat frame through the mesh cover as shown.

Balley Mesh Bouncer


2



② Put on the front in the base.




③ Assemble the screw on both sides




Secure as shown with 2 x screws (A). Tighten with an Allen Key (B).

3



④ Open the harness by pressing the sides of the buckle



⑤ Tighten the harness by pulling the straps