


# Hello, I've arrived!

Now that I'm here you are only one flat-pack away from transforming your home.



### Thank you for supporting us.

We believe design belongs to everyone. From materials and processes to safety testing, production and delivery, we are passionate and committed to bringing you the best possible product so you can create beautifully functional spaces to feel comfortably you.

# Here are a few assembly tips before you get started:



### Make Time

The first step to all seamless assembly is taking a moment to carefully read through the instructions—you are already on your way to creating a beautifully functional space!



### Set The Mood

Put on your favourite playlist, order that pizza and pour yourself a drink to get in the mood!



### **Tool Check**

Layout the instructions, screws and panels to check you have everything you need. A blanket or soft floor rug will help protect your new favourite item from scratches and a drill will speed up the assembly too!



### Room Reveal

You did it! Take a step back and enjoy the moment. Don't forget to recycle any packaging and share a pic of your room reveal—we love seeing how you transform your home! Tag us @mockaaustralia/@mockaanz


Happy flat-packing!

the Mocka Team

### Brixton


### **Desk Drawers**


Thank you for your purchase. Please follow the instructions for correct assembly. While we took great effort to ensure these assembly instructions were correct at the time of printing, sometimes updates are required post production. For the most up to date versions please refer to the product page on our website. mocka.com.au/mocka.co.nz





### Panel Layout







### Partlist

1	Cabinet Top Panel	x1	6	Drawer Front Panels	<b>x</b> 3
2	Cabinet Bottom Panel	x1	7	Drawer Left Side Panels	x3
3	Cabinet Left Side Panel	x1	8	Drawer Right Side Panels	х3
4	Cabinet Right Side Panel	x1	9	Drawer Back Panels	х3
5	Cabinet Back Panel	x1	10	Drawer Bottom Panels	х3





WARNING: Any furniture that is not anchored to a wall has the potential to tip over in certain circumstances, i.e. if a child attempts to climb up on the furniture or in the event of an earthquake. Accordingly, we recommend that all furniture is anchored to a wall. We supply a free safety wall anchor with all furniture sold and we recommend these are used to prevent your product tipping. The fixing device provided should fit most wall types, but please note that different wall materials may require different fixing devices from those supplied.




Phillips screwdrivers required.

For quicker assembly, we recommend the use of a power drill on a low-speed setting.




1






2







3



Hardware Needed			
F	<b>B</b>	x16	
K	<b>6</b>	x2	
L	8	x2	






6


# Desk Drawers That ware Needed C x4 D x4 D x4

Hardware Needed
C x4

7



8



Mocka.


Hardware Needed

## Brixton

**Desk Drawers** 


9






10

Hardware Needed				
I		х3		
J	$\Diamond$	х3		







11




12

Hardware Needed				
Е	E2 E4	х3		
F	<b>B</b>	x12		







13



14




Hardware Needed				
F	<b>B</b>	x2		
0	[]	x2		




15





16



Hardware Needed
P x16

Cover locking nuts with stickers (P)

You're done, enjoy!