

Assembly Instructions

Thank you for your purchase.

Please follow the instructions below for correct assembly.






Phillips & Flathead screwdrivers required.

For quicker assembly, we recommend the use of a power drill on a low-speed setting.





Read the instructions carefully. Refer to the hardware and furniture parts list for guidance. Be sure all of the pans are complete before assembling. Place all of the wooden furniture parts on a clean and flat soft surface to prevent scratches.

Refer to the steps provided as an assembling guide.


CAUTION:

- 1. Do not tighten the nuts or nut bolts completely until they are all in place.
- 2. To avoid thread damage, avoid overtightening nuts or nut bolts.
- 3. Hardware is to be kept out of reach of children.


Assembly Instructions

mocka

1



2



Attach 1 x box frame (4), 1 x front leg (2) and 2 x side stretcher (3) together and secure with 4 x 80mm bolts (B), 4 x spring washers (D) and 4 x flat washers (E). Attach stretchers (3) and secure with 2 x 32mm screws (F). Tighten with an allen key (G).


Attach 1 x chair back (1) to assembled frame and secure with 2 x 35mm screws (C), 2 x spring washers (D) and 2 x flat washers (E). Tighten with an allen key (G).


Assembly Instructions

mocka

3

4






Secure with 4 x 90mm bolts (A), 4 x spring washers (D) and 4 x flat washers (E). Attach stretchers (3) and secure with 2 x 32mm screws (F). Tighten with an allen key (7).

Attach 1 x chair seat (5) to assembled frame and secure with 5 x 32mm screws (F). Tighten with a screwdriver.

Assembly Instructions

mocka

5



Once assembled lift furniture into place, do not drag. Ensure unit is balanced and steady before use. You're done, enjoy!