



# Kids Cubby House

## Assembly Instructions

# mocka

Thank you for your purchase.  
Please follow the instructions below for correct assembly.




Phillips screwdriver required.

For quicker assembly, we recommend the use of a power drill on a low-speed setting.

### **WARNING!**

Not suitable for children under 3 years of age



# Kids Cubby House

## Assembly Instructions

mocka

### Safety

**WARNING** - Only adults should assemble or disassemble this product.

**WARNING** - This product may contain sharp edges and small parts prior to assembly - product must be assembled by an adult

**WARNING** - This product is safely designed for children between the ages of 3 years and up.

**WARNING** - Adult supervision of children is required at all times when on or around this product. We advise that parents should observe and ensure that their children have the strength and skills to enjoy all the equipment safely before using them on their own.

**WARNING** - To prevent serious injury do not allow children to play on the product until it is completely assembled and installed.

**WARNING** - Children using this product should only use the product in the manner intended. i.e. do not climb on the unit.

**WARNING** - This unit must be placed on a level surface at least 2m from any structure or obstruction such as a fence, garage, house, overhanging branches, laundry lines or electrical wires.

**WARNING** - Not to be installed over concrete asphalt or any other hard surface.

**WARNING** - Modifications made to this product (e.g. adding an accessory) shall be carried out according to the instructions of the manufacturer.

### Timber

Our product was manufactured from premium timber with great care dealt in selecting, machining and treating the timber before it is sold to you.

Bear in mind that timber is a natural product and may experience changes throughout the course of its life. It may:

- Develop openings (gaps, slits, apertures, cracks) along the line of the grain. This occurs due to moisture content between internal and outer surfaces of the timber. It is totally acceptable and will not affect the integral strength, life or guarantee of the product.
- Fade as the timber reacts with sunlight. The timber should be treated with a proprietary product to act as a protective barrier (i.e. a water repellent on an annual basis)
- Warp and distort its shape. Any distortion will be slight and will not affect the safety or enjoyment of this product.

### Care and Maintenance

We recommend regular maintenance should be conducted at the beginning of each season for your play equipment to ensure all main parts/fixings are tightly secured, well-oiled and intact to avoid injury or hazard.

We advise the following tips where applicable:


1. Tighten all hardware, but do not over tighten , as this may crack the wood.
2. Lubricate all metallic moving parts.
3. Check all protective coverings on bolts, pipes, edges and corners. Replace if they are loose, cracked or missing.
4. Check metal parts for rust. Replace as needed.
5. Prevent weathering by applying protective barriers to your timber via proprietary products to maintain its quality.
6. Attachments must be regularly examined for evidence of deterioration. Replace any attachments if there are signs of deterioration.

# Kids Cubby House

## Assembly Instructions


mocka

1



Attach 1 x door stop (C) to the inside of panel [1] and secure with 2 x small screws (B). Tighten with a screwdriver.

2




Attach 2 x panels [4] to panel [2] and secure with 6 x long screws (A). Tighten with a screwdriver.

# Kids Cubby House

## Assembly Instructions


mocka

3



Attach panel [1] to 2 x panels [4] and secure with 6 x long screws (A). Tighten with a screwdriver.

4




Attach 2x panel [5] to panels [1] and panel [2] and secure with 8 x small screws (B). Tighten with a screwdriver.

# Kids Cubby House

## Assembly Instructions


mocka

5



Attach panel [3] to panels [5] and secure with 4 x small screws (B). Attach 3 x panels [6] to the windows in panels [4] and [2] and secure with 9 x small screws (B). Tighten with a screwdriver.

6



Attach 4 x panels [7] to panel [5] and secure with 12 x small screws (B). Tighten with a screwdriver. Once assembled lift into place, do not drag. You're done, enjoy!