



Kids Shelf Unit

Assembly Instructions

Thank you for your purchase.
Please follow the instructions below for correct assembly.



Phillips & Flathead screwdrivers required.

For quicker assembly, we recommend the use of a power drill on a low-speed setting.

mocka


WARNING: Any furniture that is not anchored to a wall has the potential to tip over in certain circumstances, i.e. if a child attempts to climb on the furniture or in the event of an earthquake. Accordingly, we recommend that all furniture is anchored to a wall. We supply a free safety wall anchor with all furniture sold and we recommend these are used to prevent your product tipping. The fixing device provided should fit most wall types, but please note that different wall material may require different fixing devices from those supplied.

WARNING: Due to the small size of the hardware and the sharp points of the screws, they are potentially hazardous.

Keep all assembly parts and packaging materials out of reach of children.

Retain packaging information for future reference.

Adult assembly required.





Kids Shelf Unit

Assembly Instructions


mocka

1



Insert 6 x dowels (A) into panels [5] and [6] as shown. Attach panels [6] and [4] to panel [5] and secure with 2 x large screws (D), 4 x bolts (B) and 4 x locking nuts (C). Tighten with a screwdriver.

2





Insert 4 x dowels (A) into panels [6] as shown. Attach panel [7] to panels [6] and secure with 4 x large screws (D). Tighten with a screwdriver.

Kids Shelf Unit

Assembly Instructions


mocka

3



Insert 4 x dowels (A) into panel [7] as shown. Attach panels [8] to panel [7] and secure with 4 x bolts (B) and 4 x locking nuts (C). Tighten with a screwdriver.

4




Insert 4 x dowels into panels [8] as shown. Attach panel [9] to panel [8] and secure with 4 x large screws (D). Tighten with a screwdriver.

Kids Shelf Unit

Assembly Instructions



mocka

5



Attach 12 x bolts (B) to panels [2] and [3]. Tighten with a screwdriver.

6





Insert 4 x dowels (A) into panel [3] as shown. Attach panel [3] to assembled frame and secure with 4 x locking nuts (C). Tighten with a screwdriver.

Kids Shelf Unit

Assembly Instructions


mocka

7



Slide panels [12] and [13] into position as shown. Insert 5 x dowels (A) into and attach panel [2] to assembled frame as shown, secure with 6 x locking nuts (C). Tighten with a screwdriver.

8




Attach 6 x bolts (B) to panel [10]. Tighten with a screwdriver.

Kids Shelf Unit

Assembly Instructions


mocka

9



Slide panel [2] into position as shown. Insert 4 x dowels (A) into panel [10]. Attach panel [10] to assembled frame and secure with 6 x locking nuts (C). Tighten with a screwdriver.

10




Attach 6 x bolts (B) to panel [1]. Tighten with a screwdriver.

Kids Shelf Unit

Assembly Instructions


mocka

11



Insert 6 x dowels (A) as shown. Attach panel [1] to assembled frame and secure with 6 x locking nuts (C). Tighten with a screwdriver.

12




Unfold drawers and insert base as shown. Slide panels [14] and [15] into position as shown.

Kids Shelf Unit

Assembly Instructions


mocka

13



Attach 8 x braces (I) and 2 x wall straps (F) to assembled frame and secure with 10 x small screws (E). Tighten with a screwdriver.

14




Once assembled lift furniture into place, do not drag. Use a drill to create 2 x small holes in the wall lining up with the 2 x wall straps (F). Fasten to the wall using 2 x wall plugs (H) and 2 x screws (F). Tighten with a screwdriver.

Kids Shelf Unit

Assembly Instructions

mocka

15



Secure to wall using 2 x wall ties (G). Ensure unit is balanced and steady before use. You're done, enjoy!