


Mocka Balance Bike

Assembly Instructions

Thank you for your purchase.
Please follow the instructions below for correct assembly.



Mocka Balance Bikes are designed for children aged 2-6 years. These bikes should not be used on public roads or near traffic. Wearing a helmet is advisable. Only one child at a time should use the bike. Recommended for children under 35kgs.

Adult supervision is strongly recommended at all times. Ensure your child is confident at braking and is aware of road rules & safety. An adult should assemble and maintain the bikes to ensure safety. All screws, steering and axles must be checked by an adult before use.

Please keep your bike protected from water and moisture. Due to the wooden nature of the bike, they should not be left outside for long periods of time and should be dried down after use. We recommend storing your bike inside when not in use. Clean with a damp cloth - do not use chemical spray cleaners.

mocka




ALL nuts and bolts must be checked and tightened before first use. Regularly check all screws are tight to ensure safety.

Mocka Balance Bike

Assembly Instructions


mocka

1



The Mocka Balance Bike has been pre-assembled already. The seat is in the lowest position for a beginner rider. To complete the assembly position the frame and fork of the bike together.

2




Connect the frame and fork using the steering axle rod (A). Slide the rod down into the central hole in the top and through the end of the frame.

Mocka Balance Bike

Assembly Instructions


mocka

3



Using the two long screws (B) attach the handle bars to the top of the steering section. Tighten both screws securely with the allen key (C).

4



Use allen key (C) to release and re-tighten the pre-assembled bolts to adjust the seat. All done! We are confident your child will have years of fun and adventure while developing fantastic balance and co-ordination skills!